

Swatch Chart

Phone.0800BAGS 2 U (0800 224 728)
Fax. +64 9 279-9905 Ph. +64 9 279-9919
www.ecobags.co.nz, sales@ecobags.co.nz



Base 01
PMS 7506




Base 02
PMS 7508



Base 03
PMS 7499



Base 04
PMS 423



Base 05
PMS 1645



Base 06
PMS 7504



Base 07
PMS 715



Base 08
PMS 2728



Base 09
PMS 4705



Base 10
PMS 497



Base 11
PMS 123



Base 12
PMS 205




Base 13
PMS 376



Base 14
PMS 202



Base 15
PMS 2965



Base 16
PMS 199



Base 17
PMS 642



Base 18
PMS 340



Base 19
White



Base 20
Black



Base 21
PMS 706




Base 22
PMS 183



Base 23
PMS 7460



Base 24
PMS 260



Base 25
PMS 326



Base 26
PMS 356



Base 30
PMS 2665



Base 31
PMS 7476



Base 32
PMS 7478



Base 33
PMS 2577



Base 34
PMS 2985



Base 35
PMS 367



Base 37
PMS 361



Base 38
PMS 289



Base 39
PMS 424



D49
PMS 129



D29
PMS 130



D88
PMS 209



D19
PMS 293